

NOTE! Please try another car model DIP settings if your current car model DIP doesn't work. Disconnect and reconnect interface's power for effective after changing any DIP setting.

■ OEM RADIO AUDIO SETTINGS:

- 1. For car models with stock AUX port, make sure source switch to "AUX" mode on original car stereo for audio transmission before using the integration.
- 2. For car models with an AMI port, please plug in "AMI to AUX cable (sold separately)" then switch audio source to AMI mode.
- 3. For car models without AUX or AMI port (e.g. BMW EVO, Mercedes NTG 5, etc.), please plug in the provided "AUX-USB" adapter then switch audio source to "AUX-USB" mode.

QUICK RESTART TIPS:

Press and hold the "BACK" button for 10s will restart the integration immediately

■ WHAT'S IN THE BOX













Screen bypass cable

USB/Video cable

LVDS cable

WiFi/BT antenna

Power/CAN harness